


TATE	PROJECT	SHEET NUMBER
ID	PFH 50(9)	

LENGTH AND SPACING TABLE					
APPROACH	BUFFER SPACE LENGTH	CHANNELIZING DEVICE			
SPEED		TAPER	BUFFER	WORK	
MPH	FEET	AREA	SPACE	SPACE	
МРП		SPACING IN FEET			
25	155	20	50	50	

NOTE:

- 1. Signs are shown for one direction of travel only. Place devices similar to those depicted for the opposite direction of travel.
- Install a second, opposite hand "Reverse Curve" sign (W1-4) in advance
 of the second reverse curve back to the original alignment. Use "Reverse
 Turn" signs (W1-3) instead when the diversion has sharp curves with
 recommended speeds of 30 mph or less.
- 3. Place channelizing devices outside temporary roadway.
- 4. Do not allow equipment, materials, or vehicles to be parked or stored in the buffer space.



TEMPORARY TRAFFIC CONTROL FOR DETOUR